

Assembly instructions DexFix.









In order to facilitate the installation of frames. Svedex has developed the DexFix installation tool.

This new and handy installation tool makes the installation of frames particularly efficient and time-saving. DexFix meets all the wishes and requirements of a frame fitter:

- simple operation and action
- accurate installation
- up to 25% time-savings in terms of installation

The installation of a full-wall frame with DexFix can be up to 25% faster. You save time because the setting and fitting of the frame is easier as you do not have to use any filler plates and wedges.

Both frame posts are each fitted with three DexFix elements on the inside. In the case of frames with a wall thickness of less than 125 mm, the DexFix elements (6) are included separately in the box. The DexFix comes with adhesive tape, making it easier to place them in the marked positions on the inside of the frame. If you want, you can also screw or staple them to the frame. In the event of unevenness or another obstacle in the wall opening where you want to fit a DexFix element, you simply move the DexFix.

Installation with DexFix

First, the frame needs to be pre-installed (see the standard installation manual). You then always place the adjustable frame clamp at the level of the top and lower Dexfix elements. After pre-installing the frame and positioning it in the wall opening, you secure the two top DexFix elements uniformly using a (cordless) screwdriver (Torx 25), allowing them to unfold. This causes the DexFix elements to secure themselves between the wall and the frame, thereby fitting the frame. Now ensure the frame jambs are level and further fit the frame by also tightening the other DexFix elements. Once the frame is level and fully fitted, it has to be permanently secured in the wall opening and you have to apply installation foam all around it.

For more frame installation instructions, please consult the installation manual in the box or visit the website. If you have any other questions, please contact our Internal Sales Department +31 (0)315 25 93 70.









